GB

Milk frother

Dear Customer,
Before using the appliance, please read the following instructions carefully.

Important safety instructions
- Do not use the appliance unless the whisk head is fully submerged in the liquid.
- This appliance must not be used if the shaft is bent.
- This appliance is not intended for use by any person (including children) with reduced physical, sensory or mental capabilities, or lacking experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- No responsibility is accepted if damage results from improper use, or if these instructions are not complied with.
- In order to comply with safety regulations and to avoid hazards, repairs to electrical appliances must be carried out by qualified personnel. If repairs are needed, please send the appliance to one of our customer service departments. The addresses can be found in the appendix to this manual.

Batteries
Should the frothing process not lead to the desired results, or if you experience a decrease in the operating speed, this indicates that the batteries need to be replaced. To access the battery compartment, unlock the cover and remove it. Always ensure correct polarity alignment when inserting new batteries. The unit is designed for use with standard 'R6/AA'-type 1.5V batteries. Do not use rechargeable batteries: the operating voltage is rated at only 1,2V.
Remember to protect our environment. Never dispose of old batteries in your domestic garbage.
Old batteries must be disposed of through the local 'special garbage collection points'.
During extended periods of non-use, always remove the battery from the battery compartment.

Before using for the first time
Before the appliance is used for the first time, or after extended periods of non-use, it should be thoroughly cleaned as described in the section **General Care and Cleaning**.

Operation
We recommend the use of long-life low-fat milk (1.5% fat content). For best results, the milk should be taken from the refrigerator immediately prior to frothing.
- Half-fill a suitable, long container (eg glass or cup) with milk. Do not pre-heat the container.
- Insert the whisk head, ensuring that it is fully immersed, and press the operating button. Keep it pressed until the milk is thoroughly frothed. During frothing, the whisk head should be moved in a circular motion. To avoid possible spilling during the frothing process, ensure that the whisk head remains fully submerged.
- Use a spoon to spread the milk froth over the coffee.

General Care and Cleaning
The whisk head is permanently attached and cannot be removed. After use, the head can be easily cleaned by dipping it into warm water and briefly pressing the operating button. Clean the head thoroughly afterwards. For safety reasons, the housing of the appliance may not be treated with water or any other liquids; it may be wiped with a slightly damp cloth.

Disposal

Do not dispose of old or defective appliances in domestic garbage; this should only be done through public collection points.

Guarantee

This product is guaranteed against defects in materials and workmanship for a period of two years from the date of purchase. Under this guarantee the manufacturer undertakes to repair or replace any parts found to be defective, providing the product is returned to one of our authorised service centres. This guarantee is only valid if the appliance has been used in accordance with the instructions, and provided that it has not been modified, repaired or interfered with by any unauthorised person, or damaged through misuse.

This guarantee naturally does not cover wear and tear, nor breakables such as glass and ceramic items, bulbs etc. If the product fails to operate and needs to be returned, pack it carefully, enclosing your name and address and the reason for return. If within the guarantee period, please also provide the guarantee card and proof of purchase.